



MOUNTING INSTRUCTIONS SKI-BRAKES MEIDJO 3 (compatible on all Meidjos bindings)

INSTRUCTIONS MONTAGE STOP-SKI MEIDJO 3 (compatible sur les toutes fixations Meidjo)

- 1- Put the ski-brake in the place provided for this purpose between the low-tech plate and the base plate / Poser le stop-ski à l'endroit prévu à cet effet entre la sous-platine et la plaque arceau



- 2- Remove the cap located in the middle of the ASP (Anti-Snow Pack) plate then screw the ASP plate / Retirer le capuchon situé au milieu de la plaque ASP (Anti-Snow Pack) puis visser la plaque ASP



- 3- Insert the low-tech and continue mounting the binding as indicated on the binding instruction / Enfiler le low-tech puis continuer le montage de la fixation comme indiquée sur la notice de la fixation.

