

Change de front lever

1. Material and tools

Material:

- Red lever
- Rivet 26 mm
- Nail 3mm

Tools:

- A drill of 4 mm
- Pin hunter 3 mm
- A pair of plier



2. How to change the red lever

a) Remove the old red lever

You can use a drill to remove the riveting. You can even break the old lever to simplify the operation. You can also use a pin hunter to remove the old rivet.





The riveting remove by drilling

Document Inwild Page 1

b) Place the new front lever and the rivet

Place the new front lever and put the 26mm rivet.



Notice that the rivet is just align with the red lever

c) Press the new nail

Press the ail into the rivet with a pair of pliers



Press the nail



After pressing

Try the functions of the red lever. Do not forget to put the shoes into the lowtech to test the touting mode

Document Inwild Page 2